ZTF24aahgqwk in NGC 3443

Observation Notes

Typically a session has 60 30-second exposures in each of r' and g', but starting with 2024-04-21, there are 120 of g', because g' images were getting fainter.

ZTF24aahgwk Observation Log

```
In [ ]: # THIS COMMENT IS THE LONGEST A LINE CAN BE AND STILL RENDER COMPLETELY WHEN PRINTING IN LANDSCAPE MODE.
        import os
        observations directory = os.path.join(os.path.expanduser('~'), '2024 Sessions')
        analysis directory = os.path.join(os.path.expanduser('~'), 'ZTF24aahggwk analysis')
        import numpy as np
        from astropy import units as u
        from astropy.nddata import CCDData
        from astropy.io import fits
        from ccdproc import ImageFileCollection, combine, subtract dark, flat correct # Combiner
        import astroalign as aa
        import matplotlib.pyplot as plt
         %matplotlib inline
        # filters
        filters = ['r', 'q']
        filter full names = ["Sloan r'", "Sloan g'"]
        SLOAN R FILTER = 0
        SLOAN G FILTER = 1
```

```
# exposure durations
light exposure = 30 * u.second
flat exposure = 0.1 * u.second
dark exposure = light exposure # our method presumes this equality
bias exposure = flat exposure # our method presumes this equality
def confirm fits header(image, dimensions, exposure time, binning, camera set temperature, filter):
    header = image.header
    assert header['NAXIS1'] == dimensions[0]
    assert header['NAXIS2'] == dimensions[1]
    assert header['EXPTIME'] == exposure time
    assert header['XBINNING'] == binning
    assert header['SET-TEMP'] == camera set temperature
    if filter:
        assert header['FILTER'].rstrip() == filter
# Trimmed image reader utility (because the 3x3 binned images have a final row of zeros)
def delete last rows and columns (arr, rows to delete, columns to delete):
    row count = np.shape(arr)[0]
    arr = np.delete(arr, slice(row count - rows to delete, row count), 0)
    column count = np.shape(arr)[1]
    arr = np.delete(arr, slice(column count - columns to delete, column count), 1)
    return arr
def trimmed image reader(file):
    img = CCDData.read(file, unit=u.adu)
    data = img.data
    trimmed data = delete_last_rows_and_columns(data, 1, 0)
    img.data = trimmed data
    return imq
def observation directory for date(observation date):
    return os.path.join(os.path.expanduser('~'), '2024 Sessions', observation date)
def light directory for filter(observation date, filter):
    observation directory = observation directory for date(observation date)
    return os.path.join(observation directory, filter)
```

```
def calibrated_directory_for_filter(observation_date, filter):
    observation_directory = observation_directory_for_date(observation_date)
    return os.path.join(observation_directory, filter, 'calibrated')

def aligned_directory_for_filter(observation_date, filter):
    observation_directory = observation_directory_for_date(observation_date)
    return os.path.join(observation_directory, filter, 'aligned')
```

Combine the Calibration Images into Masters

Calibration Images

The calibration images are in ~/2024 Sessions/2024-04-12/. In turn, ~/2024 Sessions is actually a soft link to /Volumes/Astronomy Data/2024 Sessions/2024 Sessions.

```
# Trimmed image reader utility (because the 3x3 binned images have a final row of zeros)
def delete last rows and columns (arr, rows to delete, columns to delete):
    row count = np.shape(arr)[0]
    arr = np.delete(arr, slice(row count - rows to delete, row count), 0)
    column_count = np.shape(arr)[1]
    arr = np.delete(arr, slice(column count - columns to delete, column count), 1)
    return arr
def trimmed image reader(file):
    img = CCDData.read(file, unit=u.adu)
    data = imq.data
    trimmed data = delete last rows and columns(data, 1, 0)
    img.data = trimmed data
    return imq
# darks
dark files = ImageFileCollection(dark directory).files filtered(include path='True')
darks = [trimmed image reader(file) for file in dark files]
for dark in darks:
    confirm_fits_header(dark, (1381, 940), 30.0, 3, 0.0, 'dark')
# flats by filter
flat files by filter = {filter:ImageFileCollection(flat directory).files filtered(include path='True')
                        for filter, flat directory in flat directories by filter.items()}
flats by filter = {filter:[trimmed image reader(file) for file in flat files]
                   for filter, flat files in flat files by filter.items()}
for filter, flats in flats_by_filter.items():
    for flat in flats:
        confirm fits header(flat, (1381, 940), 0.1, 3, 0.0, filter)
# biases
bias files = ImageFileCollection(bias directory).files filtered(include path='True')
```

```
biases = [trimmed image reader(file) for file in bias files]
for bias in biases:
    confirm fits header(bias, (1381, 940), 0.1, 3, 0.0, 'dark')
# Combine darks, flats, and biases
calibration combination method = 'median' # alternatively, the method can be 'average'
master dark = combine(darks, method=calibration combination method)
master flats by filter = {filter:combine(flats, method=calibration combination method)
                         for filter, flats in flats by filter.items()}
master bias = combine(biases, method=calibration combination method)
# Perform dark subtraction of the master flats
master flats subtracted by filter = {filter:subtract dark(master flat,
                                                          master bias,
                                                          data exposure=flat exposure,
                                                          dark_exposure=bias_exposure,
                                                          scale=False)
                                     for filter, master flat in master flats by filter.items()}
```

Load, Calibrate, Align, and Stack Lights

What follows is a giant for loop, done once for each observation date.

```
In []: # THIS COMMENT IS THE LONGEST A LINE CAN BE AND STILL RENDER COMPLETELY WHEN PRINTING IN LANDSCAPE MODE.

aa.PIXEL_TOL = 3 # raised this from the default of 2 due to sometimes poor seeing or wind shake

detection_sigma = 2.0 # lowered this from the default of 3.0 due to align soft images

observation_dates = [
    # SUCCESS W/ 2.5 '2024-03-20',
    # SUCCESS W/ 2.0 '2024-03-21',
    # SUCCESS W/ 2.0 '2024-03-23',
```

```
# SUCCESS W/ 3.0 '2024-03-27',
    # SUCCESS W/ 3.0 '2024-04-02',
    # SUCCESS W/ 3.0 '2024-04-03',
    # SUCCESS W/ 3.0 '2024-04-04',
    # SUCCESS W/ 3.0 '2024-04-06',
    # SUCCESS W/ 3.0 '2024-04-10',
    # SUCCESS W/ 3.0 '2024-04-11',
    # SUCCESS W/ 2.0 '2024-04-13',
    # SUCCESS W/ 3.0 '2024-04-17',
    # SUCCESS W/ 2.0 '2024-04-21',
    # SUCCESS W/ 2.0 '2024-04-22',
    # SUCCESS W/ 2.0 '2024-04-23',
   # SUCCESS W/ 3.0 '2024-04-29',
    # SUCCESS W/ 3.0 '2024-04-30',
    # SUCCESS W/ 3.0 '2024-05-02'
observation_dates = [
    '2024-03-20',
    '2024-03-21',
    '2024-03-23',
    '2024-03-27',
    '2024-04-02',
    '2024-04-03',
    '2024-04-04',
    '2024-04-06',
    '2024-04-10',
    '2024-04-11',
    '2024-04-13',
    '2024-04-17',
    '2024-04-21',
    '2024-04-22',
    '2024-04-23',
    '2024-04-29',
    '2024-04-30',
    '2024-05-02'
```

```
for observation date in observation dates:
   observation directory = os.path.join(os.path.expanduser('~'), '2024 Sessions', observation date)
    # subdirectories for the 30-second g and r lights
   light directories by filter = {
       filter:os.path.join(observation_directory, filter)
       for filter in filters
   }
    # lights by filter
   light files by filter = {
       filter:ImageFileCollection(light directory).files filtered(include path='True')
       for filter, light_directory in light_directories by filter.items()
   }
   lights by filter = {
       filter:[trimmed image reader(file) for file in light files]
       for filter, light files in light files by filter.items()
    for filter, lights in lights by filter.items():
       for light in lights:
            confirm_fits_header(light, (1381, 940), 30.0, 3, 0.0, filter)
    subtracted lights by filter = {
       filter:[subtract dark(light,
                              master dark,
                              data exposure=light exposure,
                              dark exposure=dark exposure,
                              scale=False) for light in lights]
       for filter, lights in lights by filter.items()
   }
    # Perform flat division
    calibrated lights by filter = {
       filter:[
```

```
flat correct(light, master flats subtracted by filter[filter])
       for light in lights
   for filter, lights in subtracted lights by filter.items()
# In this phase of the analysis, the aligned directories are written to not read from.
# create the aligned directories
aligned directories by filter = {
   filter:os.path.join(light directory, 'aligned')
   for filter, light directory in light directories by filter.items()
for aligned directory in aligned directories by filter.values():
   if not os.path.exists(aligned directory):
       os.makedirs(aligned directory)
lights_aligned with footprints_by_filter = { 'r': [], 'g': [] }
# Not using a list comprehension because it is easier with explicit loops to locate registration fail
for filter in filters:
   print(filter)
   for i in range(len(calibrated lights by filter[filter])):
       print(observation date, filter, i, light files by filter[filter][i])
       # somewhat arbitrarily, we will use the image with index 10 as the reference light
       # THE FOLLOWING CALL IS FUSSY AND OFTEN FAILS ON POOR IMAGES #
       lights aligned with footprints by filter[filter].append(
           aa.register(calibrated lights by filter[filter][i],
                      calibrated lights by filter[filter][10],
                      detection sigma=detection sigma)
# write the aligned lights
```

```
for filter in filters:
    lights = lights by filter[filter]
    light files = light files by filter[filter]
   lights aligned with footprints = lights aligned with footprints by filter[filter]
    aligned directory = aligned directories by filter[filter]
   for j in range(len(lights aligned with footprints)):
        # Then we write all the files for that filter
        light header = lights[j][0].header
        light aligned data = lights aligned with footprints[j][0]
        aligned file = os.path.join(aligned directory, os.path.basename(light files[j]))
        aligned file2 = os.path.splitext(aligned file)[0] + ' aligned.fit'
        fits.writeto(aligned file2, light aligned data, light header, overwrite=True)
# read back in and stack the lights
aligned lights by filter = {
    filter:[CCDData.read(file, unit=u.adu)
            for file in ImageFileCollection(aligned directory).files filtered(include path='True')]
   for filter, aligned directory in aligned directories by filter.items()
}
stacking combination method = 'median' # alternatively, the method can be 'average'
combined lights by filter = {
    filter:combine(lights, method=stacking combination method)
    for filter, lights in aligned lights by filter.items()
# create the directories where the stacked lights will be written
stacked directory = os.path.join(analysis directory, 'stacked')
if not os.path.exists(stacked directory):
    os.makedirs(stacked directory)
# write the aligned lights
for filter in filters:
    stacked header = aligned lights by filter[filter][0].header
```

```
stacked_data = combined_lights_by_filter[filter]
stacked_file = os.path.join(stacked_directory, observation_date + '-' + filter + '_stacked.fit')
fits.writeto(stacked_file, stacked_data, stacked_header, overwrite=True)
```