# SN ZTF24aahgqwk in NGC 3443

#### **Observation Notes**

Typically a session has 60 30-second exposures in each of g' and r'.

<u>Observation Log (https://brianhill.github.io/supernova-observation/ZTF24aahgwk\_observation\_log.html)</u>

## **Combine the Calibration Images into Masters**

#### **Calibration Images**

The calibration images are in ~/2024 Sessions/2024-04-12/. In turn, ~/2024 Sessions is actually a soft link to /Volumes/Astronomy Data/2024 Sessions/2024 Sessions.

```
flat_directories_by_filter = {filter:os.path.join(calibration_dire
                              for filter in filters}
# subdirectory for the biases (TheSky Professional Edition may ind
bias_directory = os.path.join(calibration_directory, 'bias')
# Trimmed image reader utility (needed because our images have fou
def delete_last_columns(arr, columns_to_delete):
    column_count = np.shape(arr)[1]
    del arr = np.delete(arr, slice(column count - columns to delet
    return del arr
def trimmed_image_reader(file):
    img = CCDData.read(file, unit=u.adu)
    data = img.data
    trimmed_data = delete_last_columns(data, 4)
    img.data = trimmed_data
    return ima
# darks
dark_files = ImageFileCollection(dark_directory).files_filtered(ir
darks = [trimmed_image_reader(file) for file in dark_files]
# flats by filter
flat_files_by_filter = {filter:ImageFileCollection(flat_directory)
                        for filter, flat directory in flat director
flats_by_filter = {filter:[trimmed_image_reader(file) for file in
                   for filter, flat_files in flat_files_by_filter.
# biases
bias_files = ImageFileCollection(bias_directory).files_filtered(ir
biases = [trimmed_image_reader(file) for file in bias_files]
# Combine darks, flats, and biases
method = 'median' # alternatively, the method can be 'average'
master_dark = combine(darks, method=method)
master_flat_by_filter = {filter:combine(flats, method=method)
                         for filter, flats in flats by filter.item
master_bias = combine(biases, method=method)
```

### **Load and Align Lights**

The lights we are examining are in ~/2024 Sessions/2024-04-17/.

```
In [9]:
            observation_date = '2024-04-17'
            observation directory = os.path.join(os.path.expanduser('~'), '202
            # subdirectories for the 30-second g and r lights
            light_directories_by_filter = {filter:os.path.join(observation_dir
            # lights by filter
            light files by filter = {filter:ImageFileCollection(light director
                           for filter, light_directory in light_directories_by
            lights_by_filter = [[trimmed_image_reader(file) for file in light]
                                for filter, light_files in light_files_by_filt
            # the aligned directories are written to not read from
            aligned_directories_by_filter = {filter:os.path.join(light_directd
                                              for filter, light_directory in li
            for aligned_directory in aligned_directories_by_filter.values():
                if not os.path.exists(aligned_directory):
                    os.makedirs(aligned directory)
```

In []: 1